HANECO LED BATTEN INSTALLATION GUIDE

Thanks for choosing our BLADE G2 batten series products. We strongly recommend that you read this manual carefully before installation.



The luminaire must be installed by a professional electrician. Switch power off when wiring the luminaire. Ensure input voltage conforms to the voltage range of product. Ensure wires are securely connected. Before switching on, ensure that all the wiring is correct. The warranty is void if product is not installed according to the instructions.

MODEL	POWER	VOLTAGE	FREQUENCY	DIMENSIONS
BLADE06-TRI	20W	AC 220-240v	50/60Hz	620 x 100 x 30mm
BLADE12-TRI	40W	AC 220-240v	50/60Hz	1215 x 100 x 30mm

Installation Instructions























