

Smartbright 'Tri-Colour' Weatherproof Bulkhead WL020C

Mounting instruction VI.0





Application



	W8	16W
Inom/Run current(mA)	40	73
Ipeak(A)	5	5
Twidth(ms)	0.34	0.42
AC Leakage Current(uA)	10	10
MCB(Type B 16A, pcs)	50	26

- 1. Read this entire manual before you start to install the luminaire.
- 3. The luminaire shall be installed by a qualified electrician according to specified steps, and wired in accordance with the latest IEE electrical regulations or the national requirements.
- 4. TURN OFF the power during installation or maintenance to avoid electrical shock.
- 5. For indoor and semi outdoor use, not suitable for public outdoor.
- 6. The light source of this luminaire is not replaceable; when the light source reaches its end of life the whole luminaire shall be replaced.
- 7. Luminaire must not be used or stored in corrosive environment where hazardous materials such as Sulphur, Chlorine, Phthalates, etc., are present.



